



HOW TO OPERATE A SPECTANK®:

Installing the Spectank®

- Fill the Spectank® with water (preferably hot) to the level line indicated on inside back wall of tank.
- Insert plug into the wall socket and switched on. Both lights should initially be on – the left indicator light will toggle on and off once the temperature is reached. **Switch unit off only** when servicing.
- Ensure the water is hot -70 to 80 deg Celsius. It can take up to 24 hours to heat the Spectank up.
- Empty 1 x 6kg bag of Carbsolve dishwashing powder into the Spectank and mix using the basket.
- Wear safety equipment while operating - (water is hot) etc.

Loading the Spectank®

- Lift the lid. Ensure it is secure and will not fall down.
- By holding the handles of the basket inside the tank, slowly raise the basket.
- Support the basket by inserting the hooks on the side of the Spectank unit into the holes in the side of the basket handle.
- Load the Spectank® basket with equipment to be cleaned.
- Slightly lift basket and remove off hooks on side of tank.
- Slowly submerge basket into solution – water will splash up if allowed to submerge too quickly.
- Fill Spectank® with additional equipment.
- Close lid.
- Allow to soak for between 1 and 24 hours as required.

Unloading the Spectank®

- Lift the lid. Ensure it is secure and will not fall down.
- By holding the handles of the basket, slowly raise the basket.
- Support the basket by inserting the hooks on the side of the tank into the holes in the side of the handle. Ensure the basket is raised to either the lowest or second lowest hole.
- Remove equipment making sure to be using heat resistant rubber gloves.
- Rinse equipment thoroughly with clean warm water.
- Reload the Spectank® basket with equipment to be cleaned.
- Lower basket as above and close lid.

Servicing the Spectank® - ONCE A MONTH ONLY

- Remove the power cord from the wall socket
- Drain the Spectank of the used solution and clean – See “HOW TO CLEAN A SPECTANK®”
- Continue as per instructions listed under - ***Installing the Spectank®***.