



Hospitality Cleaning Services Inc.
200 Viceroy Road, Unit 15
Vaughan, Ontario, L4K 3N8

info@hcleanings.com
Tel: (905) 762-1293
Fax: (905) 762-1333

HOW TO OPERATE A SPECTANK®:

- Check unit is plugged into the wall socket and switched on. At least one light should be on
- Ensure water is filled to water level line indicated on inside back wall of tank
- Ensure the water is hot -70 to 80 degrees Celsius
- Wear safety equipment – insulated rubber gloves (water is hot)

LOADING THE SPECTANK®:

- Lift the lid. Ensure it is secure and will not fall down
- By holding the handles of the basket, slowly raise the basket
- Support the basket by inserting the hooks in the side of the tank into the holes in the side of the handle. Ensure the basket is raised to either the lowest or second lowest hole
- Load the Spectank® basket with equipment to be cleaned
- Slightly lift basket and remove off hooks on side of the tank
- Slowly submerge basket into solution – water will splash up if allowed to submerge too quickly
- Fill Spectank® with additional equipment
- Close lid
- Allow to soak for between 1 and 24 hours as required

UNLOADING THE SPECTANK®:

- Lift the lid - ensure it is secure and will not fall down
- By holding the handles of the basket, slowly raise the basket
- Support the basket by inserting the hooks in the side of the tank into the holes in the side of the handle. Ensure the basket is raised to either the lowest or second lowest hole
- Remove equipment making sure to be using heat resistant rubber gloves (equipment and water is hot)
- Rinse equipment thoroughly with clean warm water
- Reload the Spectank® basket with equipment to be cleaned
- Lower basket as above and close lid